

## 92. Recommended spare parts: AP, APG

50/60 Hz


### Customer Information

Project title:	Customer name:
Reference number:	Customer number:
Customer contact:	Customer phone number: ( )
	Fax number: ( )

### Pump information

### Quotation made by

Type		Prod. No.	
P.c.	∅ mm	No.	
▽	T °C	IP	Insul. class:
Model	Pol	Hz	V
P./P <sub>2</sub>	kW	I <sub>N</sub>	A <sub>Start</sub> A <sub>N</sub> /min
Cosφ		Weight	kg
Ex			

**GRUNDFOS**   
CH-6105 Schachen

Company name:

Prepared by:

Phone number: ( )

Fax number: ( )

Date:

Quote number:

### Recommended spare parts

Kit - Spare - Bulk	Recommended service parts						Product number
	1 pump		2 to 3 pumps		4 to 7 pumps		
	2 years units per pump	5 years units per pump	2 years units per pump	5 years units per pump	2 years units per pump	5 years units per pump	
Kit, Wear Part Kit	1	2	2	3	4	8	
Oil*	1	2	2	3	4	8	

\* See service instruction for amount and type.

Above recommendations are based on:

Agitators running in normal operation should be checked every 3000 operating hours or at least once a year.  
If the stirred liquid is very muddy or sandy, check the pump at shorter intervals.