

96. Recommended spare parts: DP, EF AUTO_{ADAPT}

50/60 Hz

Customer Information

Project title:	Customer name:
Reference number:	Customer number:
Customer contact:	Customer phone number: ()
	Fax number: ()

Pump information

Quotation made by

Type:		
Model:		
P.c.		
IP68	∇	m
Hmax: m	Qmax:	l/s
P1: kW	P2:	kW
		A
n: min ⁻¹	Cosφ :	
Weight: kg	Tmax. :	°C
Cap. opr.: μF		Hz
	Insul.class:	
Made in Tatabanya. Hungary		

Company name:

Prepared by:

Phone number: ()

Fax number: ()

Date:

Quote number:

Recommended spare parts

Kit - Spare - Bulk	Recommended service parts						Product number
	1 pump		2 to 3 pumps		4 to 7 pumps		
	2 years units per pump	5 years units per pump	2 years units per pump	5 years units per pump	2 years units per pump	5 years units per pump	
Kit, Shaft seal	1	2	2	3	4	8	
Kit, O-ring	1	2	2	3	4	8	
Kit, Impeller	0	1	0	2	0	4	
Kit, Bearing	0	1	0	2	0	4	
Kit, Dry-running sensor*	0	1	0	1	0	1	
Kit, level sensor*	0	1	0	1	0	1	
Oil**	0	1	0	1	0	1	

* Only for AUTO_{ADAPT}.

** See service instruction for amount and type.

Above recommendations are based on:

Agitators running in normal operation should be checked every 3000 operating hours or at least once a year.
If the stirred liquid is very muddy or sandy, check the pump at shorter intervals.